## Instructions

## **HID Machine Stand Assembly**

- 1. Remove carton.
- 2. a. If door model open door, locate key and legs.
  - b. If basic model remove the 6 screws holding the back panel in place and then locate the legs.
- 3. Remove 4 bolts holding stand to skid. **Important: Save the square nuts for the next step.**
- 4. Attach legs to stand. Place stand on its side, insert legs thru clearance holes in base and inside the stand thread a square 5/8-11 nut onto each leg's threads. Tighten with wrench.

Tip: Rotate all 4 leg feet to the minimum height before starting to level the stand.

- 5. Hoist HID dispenser and place on stand, do not slide. Dispenser will drop slightly when correctly located.
- 6. Center dispenser left to right. Position dispenser and stand so that their backs are flush.
- 7. Secure dispenser to stand with four 3/8" bolts and lock washers provided.
- 8. a. If door model close door.
  - b. If basic model secure back panel in place with the 6 screws removed in step 2.
- 9. Place stand and dispenser in its location and rotate leg feet to level it front to back and left to right.
- 10. Remove protective plastic from panels.
- 11. Seal between stand and dispenser chassis (do not seal drip tray) with food grade sealant as needed for local codes.
- 12. If door model check lock operation, give key to user.

Note: Door swing is reversible. Hinges have to be moved to the opposite side to change swing.